

Tuesday, April 19. 2016

NVMe hotplug

As i get some questions about it in recent times: With a normal SATA/SAS disk you can simply unplug a disk without warning and preparation. NVMe are different. For all practical purposes they are PCI devices. And they want to be handled as such. Unplugging a NVMe drive without using the proper procedure is pretty much like yanking out a PCI card without preparation. So when you want to remove a NVMe disk you have to use the hotplug command in Solaris. To cite the documentation:

```
# hotplug list -lc
```

```
Connection State  Description  
Path
```

```
-----  
pcie13  ENABLED  PCIe-Native /pci@7a,0/pci8086,2f08@3/pci111d,80b5@4
```

```
# hotplug poweroff pcie13
```

```
# hotplug list -lc
```

```
Connection State  Description  
Path
```

```
-----  
pcie13  PRESENT  PCIe-Native /pci@7a,0/pci8086,2f08@3/pci111d,80b5@4
```

On a Oracle server a "OK to remove" light will turn on. Now it should appear as empty.

```
# hotplug list -lc
```

```
Connection State  Description  
Path
```

```
-----  
pcie13  EMPTY   PCIe-Native /pci@7a,0/pci8086,2f08@3/pci111d,80b5@4
```

For replacement, wait 10 seconds after removal. Then insert the new NVMe drive. You have to enable it before using it.

```
#hotplug enable pcie13
```

```
# hotplug list -lc
```

```
Connection State  Description  
Path
```

```
-----  
pcie13  Enabled  PCIe-Native /pci@7a,0/pci8086,2f08@3/pci111d,80b5@4
```

Posted by Joerg Moellenkamp in English, Oracle, Solaris at 22:34